

Delica Starwagon 4WD Operation

Make sure vehicle is **stopped in Neutral (N) or Park (P)** and Parking brake on.

Select 4wd with small shifter knob.

Push forward once for 4wd High (Normal)

Push forward and diagonally right to engage super low range

4WD light on dash (Green) should appear at bottom of Drive range indication.

Place Drive range shift in "Drive" (D) and move forward slowly.

You will hear both hubs "clunk" as they lock in.

"Wheel Lock" light should also come on on Dash Instrument.

Note 1: Once in 4WD, and Wheel lock light lit, you can shift in and out of 4WD while in motion in Normal 4WD Only!

Note 2: Stop vehicle completely to shift into 4WD Super Low range. Do not exceed 50Kph while in Super Low Range.

To Disengage 4WD completely, Stop vehicle and reverse for 10 meters until Wheel Lock light goes out.